

10.1 | Overview

September 2026

Contents

10.1 | Overview

10.1 | Overview

Before troubleshooting:

- Confirm all system components are correctly installed
- Verify all connectors are fully seated and undamaged
- Ensure the system has been configured correctly within **Level COMMAND**
- Confirm all machine power and hydraulic systems are operating normally

If an issue cannot be resolved using the information below, contact T3RRA support.