

Exporting a Field Level II for FMX/TMX (*gps) display

March 2025

Contents

Exporting a Field Level II for FMX/TMX (*gps) display

Exporting a Field Level II for FMX/TMX (*gps) display

The .gps file is used in Trimble displays. We support exporting files for these systems with a design surface, a base surface, linework, and markers. To export this type of file:

1. Open the Export window as described here.
2. Select Field Level II FMX or TMX (*.gps) from the Export list.
3. Remove any excess surfaces and other layers. Ensure you include a marker with the name MB that has your master benchmark elevation set.
4. When you have finished adding/removing layers, click OK.

NOTE: The older FMX displays require files to be exactly 1010 KB, so you may be prompted to resize the surface.