

4.1 | Overview

All requirements in this section must be confirmed before installing the **COMMAND** system.

Failure to meet these requirements may result in improper operation or system damage.

Confirm the following before proceeding:

- Tractor compatibility
- Power supply suitability
- Communication interfaces (ISOBUS or CANBUS, RS232 NMEA 0183)

Details for each requirement are provided in the following sections.
