


## 7.2 | Units

The **Units** page allows you to select the measurement units used throughout Level COMMAND.



The available unit categories are:

- **Length / Height** – Millimetres, Centimetres, Metres, Inches, or Feet.
- **Volume** – Cubic Metres, Cubic Yards, or Cubic Feet.
- **Area** – Hectares and Square Metres, or Acres and Square Feet.
- **Speed** – Metres per second, Feet per second, Metres per minute, Feet per minute, Metres per hour, Kilometres per hour, or Miles per hour.
- **Temperature** – Degrees Celsius or Degrees Fahrenheit.

For the best experience, restart **Level COMMAND** after changing any unit settings to ensure all displays are updated consistently.

