

Surface tools overview

When a layer is selected on the right hand side, the relevant tools can be accessed in two different areas. Firstly, on the menu bar (this changes depending on which layer type is selected) and is explained below in [Surface design tools](#) and secondly, in the Layer menu on the selected tab and is explained in [Surface tools - Layer Menu](#).

