

# 3D Current Position Tracking Options

**When surveying or implementing in 3D there are 2 options available. The first option is 'Follow Tractor' and the second option is 'Stop Following'.**



**Follow Tractor**

**This option keeps the tractor at the center of the screen at all times, the camera will be placed behind the tractor when pressed.. While in 3D viewing the camera can only be moved to view the tractor from various angles and will rotate with the tractor as the primary focus.**



**Stop Following**

**This option stops the camera from following the tractor. While using this option the tractor is able to drive off the edge of the screen and the camera will not follow it, however whenever a change is made to the camera angle it will snap back to the tractor's current position and use the tractor as the focal point.**

---