



5. Progress bars

In the upper right of the screen are 2 percentage counters that show the amount completed. These are only shown when 'Enable as-applied calculations' is turned on.



NOTE: the percentages count up what has been implemented so far, not what is left to do. When pausing work part way through a job save the project in order to retain completion percentages.