


# 'As-Applied' not updating correctly

## Symptoms:

When on the implementation screen, the "As-Applied" Cut/Fill map was not updating as per pass on the field.

## Cause:

Ensure the "Implement Width" is entered and they have "As -



## Solution:

If "Implement Width" is entered and "As -Applied" is enabled, make sure you have selected in "View Settings" the "Terrain" As-Applied and "Layer" Cut/Fill maps. If 'As Applied' button is unavailable, it is a good indication that As Applied is disabled in Settings.

