

# Can't find an onscreen keyboard.

## Symptoms:

**You need to enter text (like a filename) while running T3RRA software but you can't figure out how to.**

## Cause:

**Microsoft Windows has at least one onscreen keyboard available to use for text input on tablets. However it can sometimes be challenging to find it.**

**Windows may be set to desktop mode and the Keyboard won't automatically open when a text box is selected,**

## Solutions:

**There are 2 current solutions to this problem.**

- 1. Plug a physical keyboard into your tablet**
- 2. Swipe in from the "right" side of the screen and check if tablet mode is on/off, the icon should be highlighted blue if tablet mode is on.**

**If tablet mode is on press the small image of a keyboard on**

**the task bar in the lower right corner of the screen (in case you have moved the taskbar the keyboard icon should be next to the clock).**

- 3. The onscreen keyboard may not be enabled. Go into Settings>Devices>Typing and scroll down to find a toggle option labelled "Show the touch keyboard when not in tablet mode and there's no keyboard attached".**
-