

Paddle pots are backwards for manual control of cross slope.

Symptoms:

The operator is accustomed to moving the controls in one direction to achieve left tilt and in the other for right tilt. iGrade v1 wants the cross slope ram hoses in a certain way and this forces manual control to be backwards from how the operator expects.

Cause:

iGrade v1 only allows the hoses to be plugged in one configuration.

Solutions:

Short of altering the hydraulic hose configuration on the implement rams, there is no known solution for iGrade v1.

iGrade v2 gives the option of reversing the outputs.

