

Poor as-applied coverage.

March 2025

Contents

Poor as-applied coverage.

Poor as-applied coverage.

Symptoms:
The as-applied map looks blotchy, streaky, incomplete, or otherwise incorrect.

Cause:

- The as-applied map will only be correct for a single machine working in a field. If part of the field is done by another machine this information will not be relayed to the current machine.
- Blade shift is altering the implementation of the design.
- Pixel size on screen is too large.

Solutions:

1. Ensure the machine and implement settings are correct to allow as-applied to work correctly.
2. Ensure your pixel size is no more than half the implement width you are using.
    a. Pixel size can be adjusted in the “Projects” tab of settings.
    b. It is recommended to select the option closest to ⅓ of your implements width and no more than ½ of its width.
3. Check your zero range setting. Some very low zero range settings can give undesirable results.
4. Ensure your blade shift is set to zero, the blade nudge will apply above or below the design updating the as-applied to show the work is not complete.
    a. If blade shift is on in the T3RRA software it will be seen in the lower left of the screen.
    b. If the shift value here is not zero press the up and down arrows until it is zero.
    c. Do not use the blade shift function for shifts that are meant to be permanent. Alter the vertical offset value for this purpose (ie., re-zero)